2023 Farm truck rules

GENERAL

- 1. Any Truck, van SUV, mini van up to and including 3/4 ton chassis. NO COMMERCIAL OR 1 TON FRAMES will be allowed. NO 4WD Or AWD. Max 8 lug axles and spindles. Any question on truck, please ask.
- 2. NO WELDING. Two wires or chains per door. Two wire hold downs for hood. Two wire hold downs for trunks. No additional material may be added
- 3. Move battery to passenger side floor board or front seat area bolted to the floor in a secured box NO zip screws will be accepted. Ratchet straps tighten in the seat will be allowed.
- 4. Move gas tank. (make sure its secure, no zip Screws)
- 5. FACTORY shifter. or simply threaded rod or aftermarket allowed
- 6. ANY AIR FILLED TIRE NO SOLIDS AND NO SOLID WHEEL CENTERS, MAY RUN A SMALL MULTI LUG WHEEL CENTER
- 7. No aftermarket parts... A transmission cooler (fan or ice) will be allowed must be secured
- 8. Stock pedals or aftermarket brake and gas pedal allowed
- 9. Any OEM car bumper can be used or 4x4 1/4 wall square tube must be capped with a 2inch inspection hole in each end. You will be allowed (2) 6 inch plates to hold your bumper on ONLY, bumper can be welded on, FRONT AND REAR bumper must have 9 wire or chain in two locations thru sheetmetal (core support or hood) to hold them on .. IT may go to the frame but must go thru existing hole or a factory bolt.. DO NOT WELD the chain to the frames.. chain no bigger than 5/16 and no more than 3 strands of 9 wire.
- 10. No suspension modifications
- 11. No body creasing
- 12. No tucking, wedging or folding of bedside will be allowed
- 13. No added bumper shocks
- 14. Headers will be allowed
- 15. You can weld your rear center to make it posi
- 16. Motor swaps allowed weld the factory mounts in and that is it
- 17. No excessive mounts (max 8 inches of weld per mount)
- 18. No added steel
- 19. No cradles
- 20. Factory trans mount and cross-member/

- 21. A 4-point cage will be allowed for driver protection only! Anything in excess will be forced to cut or loaded at judge's discretion.
- 22. you may bolt the bed to the cab in 3 spots with bolts or threaded rod no larger than 5/8's with washer no more than 3inch X3 inch
- 23. DO NOT WELD...IF IT DID NOT COME OFF THE FACTORY FLOOR DO NOT DO IT.